



PowerFlex 70 Adjustable Frequency AC Drive

When reading this document, look for this symbol “ **Step x** ” to guide you through the **5 BASIC STEPS needed to install, start-up and program the PowerFlex 70. The information provided Does Not replace the User Manual and is intended for qualified drive service personnel only.** For detailed PowerFlex 70 information including application considerations and related precautions refer to the following:

Title	Publication	Available...
PowerFlex 70 User Manual	20A-UM001...	on the CD supplied with the drive or at www.ab.com/manuals/dr
PowerFlex Reference Manual	PFLEX-RM001...	

For Allen-Bradley Drives Technical Support:

Title	Online at...
Allen-Bradley Drives Technical Support	www.ab.com/support/abdrives

Step 1 Read the General Precautions



ATTENTION: This drive contains ESD (Electrostatic Discharge) sensitive parts and assemblies. Static control precautions are required when installing, testing, servicing or repairing this assembly. Component damage may result if ESD control procedures are not followed. If you are not familiar with static control procedures, reference A-B publication 8000-4.5.2, “Guarding Against Electrostatic Damage” or any other applicable ESD protection handbook.



ATTENTION: An incorrectly applied or installed drive can result in component damage or a reduction in product life. Wiring or application errors, such as, undersizing the motor, incorrect or inadequate AC supply, or excessive ambient temperatures may result in malfunction of the system.



ATTENTION: Only qualified personnel familiar with adjustable frequency AC drives and associated machinery should plan or implement the installation, start-up and subsequent maintenance of the system. Failure to comply may result in personal injury and/or equipment damage.



ATTENTION: To avoid an electric shock hazard, verify that the voltage on the bus capacitors has discharged before performing any work on the drive. Measure the DC bus voltage at the +DC terminal of the Power Terminal Block and the -DC test point (refer to the User Manual for location). The voltage must be zero.



ATTENTION: Configuring an analog input for 0-20mA operation and driving it from a voltage source could cause component damage. Verify proper configuration prior to applying input signals.



ATTENTION: Hazard of personal injury or equipment damage exists when using bipolar input sources. Noise and drift in sensitive input circuits can cause unpredictable changes in motor speed and direction. Use speed command parameters to help reduce input source sensitivity.



ATTENTION: Risk of injury or equipment damage exists. DPI or SCANport host products must not be directly connected together via 1202 cables. Unpredictable behavior can result if two or more devices are connected in this manner.



ATTENTION: The “adjust freq” portion of the bus regulator function is extremely useful for preventing nuisance overvoltage faults resulting from aggressive decelerations, overhauling loads, and eccentric loads. It forces the output frequency to be greater than commanded frequency while the drive’s bus voltage is increasing towards levels that would otherwise cause a fault; however, it can also cause either of the following two conditions to occur.

1. Fast positive changes in input voltage (more than a 10% increase within 6 minutes) can cause uncommanded positive speed changes; however an “OverSpeed Limit” fault will occur if the speed reaches [Max Speed] + [Overspeed Limit]. If this condition is unacceptable, action should be taken to 1) limit supply voltages within the specification of the drive and, 2) limit fast positive input voltage changes to less than 10%. Without taking such actions, if this operation is unacceptable, the “adjust freq” portion of the bus regulator function must be disabled (see parameters 161 and 162).
2. Actual deceleration times can be longer than commanded deceleration times; however, a “Decel Inhibit” fault is generated if the drive stops decelerating altogether. If this condition is unacceptable, the “adjust freq” portion of the bus regulator must be disabled (see parameters 161 and 162). In addition, installing a properly sized dynamic brake resistor will provide equal or better performance in most cases.

Note: These faults are not instantaneous and have shown test results that take between 2 and 12 seconds to occur.

EMC Instructions

CE Conformity⁽¹⁾

Conformity with the Low Voltage (LV) Directive and Electromagnetic Compatibility (EMC) Directive has been demonstrated using harmonized European Norm (EN) standards published in the Official Journal of the European Communities. PowerFlex Drives comply with the EN standards listed below when installed according to the User and Reference Manuals.

CE Declarations of Conformity are available online at:
<http://www.ab.com/certification/ce/docs>.

Low Voltage Directive (73/23/EEC)

- EN50178 Electronic equipment for use in power installations.

EMC Directive (89/336/EEC)

- EN61800-3 Adjustable speed electrical power drive systems Part 3: EMC product standard including specific test methods.

General Notes

- If the adhesive label is removed from the top of the drive, the drive must be installed in an enclosure with side openings less than 12.5 mm (0.5 in.) and top openings less than 1.0 mm (0.04 in.) to maintain compliance with the LV Directive.
- The motor cable should be kept as short as possible in order to avoid electromagnetic emission as well as capacitive currents.
- Use of line filters in ungrounded systems is not recommended.
- PowerFlex drives may cause radio interference if used in a residential or domestic environment. The installer is required to take measures to prevent interference, in addition to the essential requirements for CE compliance listed below, if necessary.
- Conformity of the drive with CE EMC requirements does not guarantee an entire machine or installation complies with CE EMC requirements. Many factors can influence total machine/installation compliance.
- PowerFlex drives can generate conducted low frequency disturbances (harmonic emissions) on the AC supply system. More information regarding harmonic emissions can be found in the *PowerFlex Reference Manual*.

⁽¹⁾ CE Certification testing has not been completed for 600 Volt class drives.

Essential Requirements for CE Compliance

Conditions 1-6 listed below **must be** satisfied for PowerFlex drives to meet the requirements of **EN61800-3**.


1. Standard PowerFlex 70 CE compatible Drive.
2. Review important precautions/attention statements throughout this manual before installing drive.
3. Grounding as described on page 1-5 of the User Manual.
4. Output power, control (I/O) and signal wiring must be braided, shielded cable with a coverage of 75% or better, metal conduit or equivalent attenuation.
5. All shielded cables should terminate with the proper shielded connector.
6. Conditions in [Table A](#).

Table A PowerFlex 70 EN61800-3 EMC Compatibility

Frame(s)	Drive Description	Second Environment				First Environment Restricted Distribution
		Restrict Motor Cable to 40 m (131 ft.)	Internal Filter Option	External Filter	Input Ferrite ⁽¹⁾	
A	Drive Only	✓		✓		See <i>PowerFlex Reference Manual</i>
	with any Comm Option	✓		✓		
	with Remote I/O	✓		✓	✓	
B	Drive Only	✓	✓			
	with any Comm Option	✓	✓			
	with Remote I/O	✓	✓		✓	
C,	Drive Only	✓				
D,	with any Comm Option	✓				
E	with Remote I/O	✓			✓	

(1) Input cables through a Ferrite Core (Frames A, B and C Fair-Rite #2643102002 or equivalent, Frames D and E Fair-Rite #2643251002 or equivalent).

Step 2 Mount the Drive – Minimum Requirements



Minimum Mounting Clearances

Specified vertical clearance requirements are intended to be from drive to drive. Other objects can occupy this space; however, reduced airflow may cause protection circuits to fault the drive. In addition, inlet air temperature must not exceed the product specification.

Maximum Surrounding Air Temperature

Enclosure Rating	Temperature Range
Open Type, IP 20, NEMA Type 1 & Flange Mount	0 - 50°C (32 - 122°F)
IP54, IP 66 & NEMA Type 4X/12	0 - 40°C (32 - 104°F)


Important: Some drives are equipped with an adhesive label on the top of the chassis. Removing the adhesive label from the drive changes the NEMA enclosure rating from Type 1 Enclosed to Open Type.

Dimensions

Table B PowerFlex 70 Frames

Output Power		Frame Size								
		208-240V AC Input			400-480V AC Input			600V AC Input		
kW	HP	Not Filtered	Filtered	IP66 (4X/12)	Not Filtered	Filtered	IP66 (4X/12)	Not Filtered	Filtered	IP66 (4X/12)
ND (HD)	ND (HD)									
0.37 (0.25)	0.5 (0.33)	A	B	B	A	B	B	A	–	B
0.75 (0.55)	1 (0.75)	A	B	B	A	B	B	A	–	B
1.5 (1.1)	2 (1.5)	B	B	B	A	B	B	A	–	B
2.2 (1.5)	3 (2)	B	B	B	B	B	B	B	–	B
4 (3)	5 (3)	–	C	D	B	B	B	B	–	B
5.5 (4)	7.5 (5)	–	D	D	–	C	D	C	–	D
7.5 (5.5)	10 (7.5)	–	D	D	–	C	D	C	–	D
11 (7.5)	15 (10)	–	D	D	–	D	D	D	–	D
15 (11)	20 (15)	–	E	E	–	D	D	D	–	D
18.5 (15)	25 (20)	–	E	E	–	D	D	D	–	D
22 (18.5)	30 (25)	–	–	–	–	D	D	D	–	D
30 (22)	40 (30)	–	–	–	–	E	E	–	E	E
37 (30)	50 (40)	–	–	–	–	E	E	–	E	E

Figure 1 PowerFlex 70 Frames A-E



Dimensions are in millimeters and (inches).

Frame	A	B	C	D	E	F	Weight ⁽¹⁾ kg (lbs.)
IP20 / NEMA Type 1							
A	122.4 (4.82)	225.7 (8.89)	179.8 (7.08)	94.2 (3.71)	211.6 (8.33)	5.8 (0.23)	2.71 (6.0)
B	171.7 (6.76)	234.6 (9.24)	179.8 (7.08)	122.7 (4.83)	220.2 (8.67)	5.8 (0.23)	3.60 (7.9)
C	185.0 (7.28)	300.0 (11.81)	179.8 (7.08)	137.6 (5.42)	285.6 (11.25)	5.8 (0.23)	6.89 (15.2)
D	219.9 (8.66)	350.0 (13.78)	179.8 (7.08)	169.0 (6.65)	335.6 (13.21)	5.8 (0.23)	9.25 (20.4)
E	280.3 (11.04)	555.8 (21.88)	207.1 (8.15)	200.0 (7.87)	491.0 (19.33)	6.9 (0.27)	18.60 (41.0)
IP66 / NEMA Type 4X/12							
B	171.7 (6.76)	239.8 (9.44)	203.3 (8.00)	122.7 (4.83)	220.2 (8.67)	5.8 (0.23)	3.61 (8.0)
D	219.9 (8.66)	350.0 (13.78)	210.7 (8.29)	169.0 (6.65)	335.6 (13.21)	5.8 (0.23)	9.13 (20.1)
E	280.3 (11.04)	555.8 (21.88)	219.8 (8.65)	200.0 (7.87)	491.0 (19.33)	6.9 (0.27)	18.60 (41.0)
Flange Mount							
A	156.0 (6.14)	225.8 (8.89)	178.6 (7.03)	123.0 (4.84)	55.6 (2.19)	–	2.71 (6.0)
B	205.2 (8.08)	234.6 (9.24)	178.6 (7.03)	123.0 (4.84)	55.6 (2.19)	–	3.60 (7.9)
C	219.0 (8.62)	300.0 (11.81)	178.6 (7.03)	123.0 (4.84)	55.6 (2.19)	–	6.89 (15.2)
D	248.4 (9.78)	350.0 (13.78)	178.6 (7.03)	123.0 (4.84)	55.6 (2.19)	–	9.25 (20.4)
E	280.3 (11.04)	555.8 (21.88)	207.1 (8.15)	117.2 (4.61)	89.9 (3.54)	–	18.60 (41.0)

(1) Weights include HIM and Standard I/O.

Step 3 Wire the Drive – Wire Recommendations

Type		Wire Type(s)	Description	Min. Insulation Rating
Power (1)	Standard	600V, 90°C (194°F) XHHW2/RHW-2 Anixter B209500-B209507, Belden 29501-29507, or equivalent	<ul style="list-style-type: none"> Four tinned copper conductors with XLPE insulation. Copper braid/aluminum foil combination shield and tinned copper drain wire. PVC jacket. 	
Signal (1) (2) (3)	Standard Analog I/O	Belden 8760/9460 (or equiv.) Belden 8770 (or equiv.)	0.750 mm ² (18 AWG), twisted pair, 100% shield with drain. 0.750 mm ² (18 AWG), 3 cond., shielded for remote pot only.	300V, 75-90 degrees C (167-194 degrees F)
Digital I/O (1) (2) (3)	Shielded	Multi-conductor shielded cable such as Belden 8770 (or equiv.)	0.750 mm ² (18 AWG), 3 conductor, shielded.	300V, 60 degrees C (140 degrees F)


- (1) Control and signal wires should be separated from power wires by at least 0.3 meters (1 foot).
- (2) If the wires are short and contained within a cabinet which has no sensitive circuits, the use of shielded wire may not be necessary, but is always recommended.
- (3) I/O terminals labeled “(-)” or “Common” are not referenced to earth ground and are designed to greatly reduce common mode interference. Grounding these terminals can cause signal noise.

Terminal Block Specifications

Name	Frame	Description	Wire Size Range ⁽¹⁾		Torque	
			Maximum	Minimum	Maximum	Recommended
Power Terminal Block	A, B & C	Input power and motor connections	3.5 mm ² (12 AWG)	0.3 mm ² (22 AWG)	0.66 N-m (5.5 lb.-in.)	0.6 N-m (5 lb.-in.)
	D	Input power and motor connections	8.4 mm ² (8 AWG)	0.8 mm ² (18 AWG)	1.7 N-m (15 lb.-in.)	1.4 N-m (12 lb.-in.)
	E	Input power and motor connections	25.0 mm ² (3 AWG)	2.5 mm ² (14 AWG)	2.71 N-m (24 lb.-in.)	2.71 N-m (24 lb.-in.)
I/O Terminal Block	All	Signal & control connections	1.5 mm ² (16 AWG)	0.05 mm ² (30 AWG)	0.55 N-m (4.9 lb.-in.)	0.5 N-m (4.4 lb.-in.)
SHLD Terminal	All	Terminating point for wiring shields	—	—	1.6 N-m (14 lb.-in.)	1.6 N-m (14 lb.-in.)

- (1) Maximum/minimum sizes that the terminal block will accept - these are not recommendations.

Power & Ground Wiring




































Standard and Enhanced Control I/O Terminal Block

No.	Signal	Factory Default	Description	Related Param.
1	Digital In 1	Stop – CF (CF = Clear Fault)	11.2 mA @ 24V DC 19.2V minimum on state 3.2V maximum off state	361 - 366
2	Digital In 2	Start	Important: Use only 24V DC, not suitable for 115V AC circuitry. Inputs can be wired as sink or source. See page 8 .	
3	Digital In 3	Auto/Man		
4	Digital In 4	Speed Sel 1		
5	Digital In 5	Speed Sel 2		
6	Digital In 6	Speed Sel 3		
7	24V Common	–		Drive supplied power for Digital In1-6 inputs.
8	Digital In Common	–	See examples on page 8 . 150mA maximum load.	
9	+24V DC	–		
10	+10V Pot Reference	–	2 k ohm minimum load.	
11	Digital Out 1 – N.O. ⁽¹⁾	NOT Fault	<u>Max Resistive Load</u> 250V AC / 30V DC	380 - 387
12	Digital Out 1 Common		<u>Max Inductive Load</u> 250V AC / 30V DC 50 VA / 60 Watts 25 VA / 30 Watts	
13	Digital Out 1 – N.C. ⁽¹⁾	Fault	<u>Minimum DC Load</u> 10 µA, 10 mV DC	
14	Analog In 1 (– Volts)	⁽²⁾	Non-isolated, 0 to +10V, 10 bit, 100k ohm input impedance. ⁽³⁾	320 - 327
15	Analog In 1 (+ Volts)	Voltage – Reads		
16	Analog In 1 (– Current)	value at 14 & 15		
17	Analog In 1 (+ Current)		Non-isolated, 4-20mA, 10 bit, 100 ohm input impedance. ⁽³⁾	
18	Analog In 2 (– Volts)	⁽²⁾	Isolated, bipolar, differential, 0 to +10V unipolar (10 bit) or ±10V bipolar (10 bit & sign), 100k ohm input impedance. ⁽⁴⁾	
19	Analog In 2 (+ Volts)	Voltage – Reads		
20	Analog In 2 (– Current)	value at 18 & 19		
21	Analog In 2 (+ Current)		Isolated, 4-20mA, 10 bit & sign, 100 ohm input impedance. ⁽⁴⁾	
22	10V Pot Common Analog Out (– Volts) Analog Out (– Current)	⁽²⁾ Output Freq	0 to +10V, 10 bit, 10k ohm (2k ohm minimum) load. 0 to 20mA, 10 bit, 400 ohm maximum load. ⁽⁵⁾ Referenced to chassis ground.	340 - 344
23	Analog Out (+ Volts) Analog Out (+ Current)		Common if internal 10V supply (terminal 10) is used.	
24	Digital Out 2 – N.O. ⁽¹⁾	Run	See description at No.s 11-13.	380 - 387
25	Digital Out 2 Common			
26	Digital Out 2 – N.C. ⁽¹⁾	NOT Run		

- (1) Contacts shown in unpowered state. Any relay programmed as Fault or Alarm will energize (pick up) when power is applied to drive and deenergize (drop out) when fault or alarm exists. Relays selected for other functions will energize only when that condition exists and will deenergize when condition is removed.
- (2) These inputs/outputs are dependent on a number of parameters. See “Related Parameters.”
- (3) Differential Isolation - External source must be less than 10V with respect to PE.
- (4) Differential Isolation - External source must be maintained at less than 160V with respect to PE. Input provides high common mode immunity.
- (5) Analog output current is only available with Enhanced Control drives.

I/O Wiring Examples



Input/Output	Connection Example ⁽³⁾		Related Param.						
<p>Potentiometer⁽¹⁾ 10k Ohm Pot. Recommended (2k Ohm minimum)</p> <p>Joystick⁽¹⁾ ±10V Input - 100k ohm input impedance</p>	<p>[Speed Ref A Sel] = "Analog In 1"</p> <table border="1" data-bbox="260 272 835 483"> <tr> <th data-bbox="260 272 524 316">Potentiometer</th> <th data-bbox="524 272 835 316">Joystick</th> </tr> <tr> <td data-bbox="260 316 524 483">  </td> <td data-bbox="524 316 835 483">  </td> </tr> </table>		Potentiometer	Joystick			<p>090 to 095</p> <p>320 to 327</p> <p>361 to 366</p>		
Potentiometer	Joystick								
									
<p>Analog Input Bipolar: ±10V</p> <p>Unipolar: 0 to +10V, 100k ohm impedance 4-20 mA, 100 ohm impedance</p>	<p>[Speed Ref A Sel] = "Analog In 2"</p> <table border="1" data-bbox="260 512 886 692"> <tr> <th data-bbox="260 512 425 555">Bipolar⁽¹⁾</th> <th data-bbox="425 512 627 555">Unipolar (Voltage)</th> <th data-bbox="627 512 886 555">Unipolar (Current)</th> </tr> <tr> <td data-bbox="260 555 425 692">  </td> <td data-bbox="425 555 627 692">  </td> <td data-bbox="627 555 886 692">  </td> </tr> </table>			Bipolar ⁽¹⁾	Unipolar (Voltage)	Unipolar (Current)			
Bipolar ⁽¹⁾	Unipolar (Voltage)	Unipolar (Current)							
									
<p>Analog/Digital Output 0 to +10V Output - Can drive a 2k Ohm load (25 mA short circuit current limit)</p>	<table border="1" data-bbox="260 692 835 901"> <tr> <th data-bbox="260 692 524 735">Analog Output</th> <th data-bbox="524 692 835 735">Digital N.O. / N.C. Output</th> </tr> <tr> <td data-bbox="260 735 524 901">  </td> <td data-bbox="524 735 835 901">  </td> </tr> </table>		Analog Output	Digital N.O. / N.C. Output			<p>341 to 344</p> <p>380 to 387</p>		
Analog Output	Digital N.O. / N.C. Output								
									
<p>2 Wire Control⁽²⁾ - Non-Reversing Requires 2-wire functions only ([Digital In1 Sel]). Using 3-wire selections will cause a type 2 alarm.</p>	<p>24V DC Input⁽⁴⁾: [Digital In2 Sel] = "Run"</p> <table border="1" data-bbox="260 930 835 1139"> <tr> <th data-bbox="260 930 524 973">Internal Supply</th> <th data-bbox="524 930 835 973">External Supply</th> </tr> <tr> <td data-bbox="260 973 524 1139">  </td> <td data-bbox="524 973 835 1139">  </td> </tr> </table>		Internal Supply	External Supply			<p>361 to 366</p>		
Internal Supply	External Supply								
									
<p>3 Wire Control Requires 3-wire functions only ([Digital In1 Sel]). Using 2-wire selections will cause a type 2 alarm.</p>	<p>24V DC Input⁽⁴⁾: [Digital In1 Sel] = "Stop - CF", [Digital In2 Sel] = "Start"</p> <table border="1" data-bbox="260 1168 835 1382"> <tr> <th data-bbox="260 1168 524 1211">Internal Supply</th> <th data-bbox="524 1168 835 1211">External Supply</th> </tr> <tr> <td data-bbox="260 1211 524 1382">  </td> <td data-bbox="524 1211 835 1382">  </td> </tr> </table>		Internal Supply	External Supply					
Internal Supply	External Supply								
									

(1) Refer to the Attention statement on [page 2](#) for important bipolar wiring information.
 (2) **Important:** Programming inputs for 2 wire control deactivates all HIM Start buttons.
 (3) Examples show hardware wiring only. Refer to [page 7](#) for parameters that must be adjusted.
 (4) If desired, a User Supplied 24V DC power source can be used. Refer to the "External" example.


Step 4 Start-Up Check List

- 1. Verify input supply voltage.
- 2. Check output wiring.
- 3. Check control wiring.
- 4. Apply AC power and control voltages to the drive.
 If any of the six digital inputs are configured to Stop – CF (CF = Clear Fault) or Enable, verify that signals are present or the drive will not start. Refer to [Troubleshooting – Abbreviated Fault & Alarm Listing on page 16](#) for a list of potential digital input conflicts.
 If the STS LED is not flashing green at this point, refer to [Status Indicators on page 9](#).
- 5. Select Start-Up method: SMART Start or Assisted Start-Up.

Status Indicators






Name	Color	State	Description
	Green	Flashing	Drive ready, but not running and no faults are present.
		Steady	Drive running, no faults are present.
	Yellow	Flashing, Drive Stopped	An inhibit condition exists, the drive cannot be started. Check parameter 214 [Start Inhibits].
		Flashing, Drive Running	An intermittent type 1 alarm condition is occurring. Check parameter 211 [Drive Alarm 1].
		Steady, Drive Running	A continuous type 1 alarm condition exists. Check parameter 211 [Drive Alarm 1].
	Red	Flashing	A fault has occurred.
Steady		A non-resettable fault has occurred.	
	Refer to the Communication Adapter User Manual.		Status of DPI port internal communications (if present).
			Status of communications module (when installed).
			Status of network (if connected).
			Status of secondary network (if connected).

Step 5 Program the Drive – Parameter Files & Groups





Frequently Used Parameters

MOTOR CONTROL (File B)	Motor Data	041 [Motor NP Volts] Set to the motor nameplate rated volts.	Default: Drive Rating Based Min/Max: 0.0/[Rated Volts] Units: 0.1 VAC	
		042 [Motor NP FLA] Set to the motor nameplate rated full load amps.	Default: Drive Rating Based Min/Max: 0.0/[Rated Amps] × 2 Units: 0.1 Amps	047 048
		045 [Motor NP Power] Set to the motor nameplate rated power. 	Default: Drive Rating Based Min/Max: 0.00/100.00 Units: 0.01 kW/HP See [Mtr NP Pwr Units] EC	046
		046 [Mtr NP Pwr Units] Selects the motor power units to be used.	Default: Drive Rating Based Options: 0 "Horsepower" 1 "kiloWatts"	
		047 [Motor OL Hertz] Selects the output frequency below which the motor operating current is derated. The motor thermal overload will generate a fault at lower levels of current.	Default: Motor NP Hz/3 Min/Max: 0.0/500.0 Hz Units: 0.1 Hz	042 220
Torq Attributes		053 Standard [Torque Perf Mode] Sets the method of motor torque production.	Default: 0 "Sensrls Vect" Options: 0 "Sensrls Vect" 1 "SV Economize" 2 "Custom V/Hz" 3 "Fan/Pmp V/Hz"	062 063 069 070
		EC [Motor Cntl Sel] Sets the method of motor control used in the drive. Important: "FVC Vector" mode requires autotuning of the motor, both coupled and uncoupled to the load. (1) Enhanced firmware 2.001 & later.	Default: 0 "Sensrls Vect" Options: 0 "Sensrls Vect" 1 "SV Economize" 2 "Custom V/Hz" 3 "Fan/Pmp V/Hz" 4 "FVC Vector" ⁽¹⁾	

MOTOR CONTROL (File B)	Torq Attributes				
SPEED COMMAND (File C)	Spd Mode & Limits	061 [Autotune]	<p> Provides a manual or automatic method for setting [IR Voltage Drop] and [Flux Current Ref], which affect sensorless vector performance. Valid only when parameter 53 is set to "Sensrls Vect" or "SV Economize."</p> <p>"Ready" (0) = Parameter returns to this setting following a "Static Tune" or "Rotate Tune." It also permits manually setting [IR Voltage Drop] and [Flux Current Ref].</p> <p>"Static Tune" (1) = A temporary command that initiates a non-rotational motor stator resistance test for the best possible automatic setting of [IR Voltage Drop]. A start command is required following initiation of this setting. The parameter returns to "Ready" (0) following the test, at which time another start transition is required to operate the drive in normal mode. Used when motor cannot be rotated.</p> <p>"Rotate Tune" (2) = A temporary command that initiates a "Static Tune" followed by a rotational test for the best possible automatic setting of [Flux Current Ref]. A start command is required following initiation of this setting. The parameter returns to "Ready" (0) following the test, at which time another start transition is required to operate the drive in normal mode. Important: Used when motor is uncoupled from the load. Results may not be valid if a load is coupled to the motor during this procedure.</p> <hr/> <p> ATTENTION: Rotation of the motor in an undesired direction can occur during this procedure. To guard against possible injury and/or equipment damage, it is recommended that the motor be disconnected from the load before proceeding.</p> <hr/> <p>"Calculate" (3) = This setting uses motor nameplate data to automatically set [IR Voltage Drop] and [Flux Current Ref].</p>	Default: 3 "Calculate" Options: 0 "Ready" 1 "Static Tune" 2 "Rotate Tune" 3 "Calculate"	053 062
		080 Standard [Speed Mode]	<p> Sets the method of speed regulation.</p>	Default: 0 "Open Loop" Options: 0 "Open Loop" 1 "Slip Comp" 2 "Process PI"	121 thru 138
		EC [Feedback Select]	<p>Selects the source for motor speed feedback. Note that all selections are available when using Process PI.</p> <p>"Open Loop" (0) - no encoder is present, and slip compensation is not needed.</p> <p>"Slip Comp" (1) - tight speed control is needed, and encoder is not present.</p> <p>"Encoder" (3) - an encoder is present.</p> <p>"Simulator" (5) - Simulates a motor for testing drive operation & interface check.</p>	Default: 0 "Open Loop" Options: 0 "Open Loop" 1 "Slip Comp" 2 "Reserved" 3 "Encoder" 4 "Reserved" 5 "Simulator"	
		081 [Minimum Speed]	<p> Sets the low limit for speed reference after scaling is applied. Refer to parameter 083 [Overspeed Limit].</p>	Default: 0.0 Hz Min/Max: 0.0/[Maximum Speed] Units: 0.1 Hz	092 095
082 [Maximum Speed]	<p> Sets the high limit for speed reference after scaling is applied. Refer to parameter 083 [Overspeed Limit].</p>	Default: 50.0 or 60.0 Hz (Dependent on voltage class) Min/Max: 5.0/400.0 Hz 5.0/500.0 Hz EC Units: 0.0 Hz	055 083 091 094 202		

SPEED COMMAND (File C)	Speed References	090 [Speed Ref A Sel] Selects the source of the speed reference to the drive unless [Speed Ref B Sel] or [Preset Speed 1-7] is selected. For more information on selecting a speed reference source, refer to the <i>PowerFlex 70 User Manual</i> , "Speed Reference Control". (1) See Appendix B of the User Manual for DPI port locations. (2) Enhanced Control Drives Only.	Default: 2 "Analog In 2" Options: 1 "Analog In 1" 2 "Analog In 2" 3-8 "Reserved" 9 "MOP Level" 10 "Reserved" 11 "Preset Spd1" 12 "Preset Spd2" 13 "Preset Spd3" 14 "Preset Spd4" 15 "Preset Spd5" 16 "Preset Spd6" 17 "Preset Spd7" 18 "DPI Port 1" ⁽¹⁾ 19 "DPI Port 2" ⁽¹⁾ 20 "DPI Port 3" ⁽¹⁾ 21 "Reserved" 22 "DPI Port 5" ⁽¹⁾ 23-29 "Reserved" 30 "HighRes Ref" ⁽²⁾	002 091 thru 093 101 thru 107 117 thru 120 192 thru 194 213 272 273 320 361 thru 366		
		091 [Speed Ref A Hi] Scales the upper value of the [Speed Ref A Sel] selection when the source is an analog input.	Default: [Maximum Speed] Min/Max: -/[+][Maximum Speed] Units: 0.1 Hz	082		
		092 [Speed Ref A Lo] Scales the lower value of the [Speed Ref A Sel] selection when the source is an analog input.	Default: 0.0 Hz Min/Max: -/[+][Maximum Speed] Units: 0.1 Hz	081		
		101 [Preset Speed 1] 102 [Preset Speed 2] 103 [Preset Speed 3] 104 [Preset Speed 4] 105 [Preset Speed 5] 106 [Preset Speed 6] 107 [Preset Speed 7] Provides an internal fixed speed command value. In bipolar mode direction is commanded by the sign of the reference.	Default: 5.0 Hz 10.0 Hz 20.0 Hz 30.0 Hz 40.0 Hz 50.0 Hz 60.0 Hz Min/Max: -/[+][Maximum Speed] Units: 0.1 Hz	090 093		
		DYNAMIC CONTROL (File D)	Ramp Rates	140 [Accel Time 1] 141 [Accel Time 2] Sets the rate of accel for all speed increases. $\frac{\text{Max Speed}}{\text{Accel Time}} = \text{Accel Rate}$	Default: 10.0 Secs 10.0 Secs Min/Max: 0.1/3600.0 Secs Units: 0.1 Secs	142 143 146 361 thru 366
				142 [Decel Time 1] 143 [Decel Time 2] Sets the rate of decel for all speed decreases. $\frac{\text{Max Speed}}{\text{Decel Time}} = \text{Decel Rate}$	Default: 10.0 Secs 10.0 Secs Min/Max: 0.1/3600.0 Secs Units: 0.1 Secs	140 141 146 361 thru 366

DYNAMIC CONTROL (File D)	Stop/Brake Modes	163	<p>[DB Resistor Type]</p> <p>Selects whether the internal or an external DB resistor will be used.</p> <p>If a dynamic brake resistor is connected to the drive, [Bus Reg Mode A & B] must be set to either option 2, 3 or 4.</p>	<p>Default: 0 "Internal Res" 2 "None" E C</p> <p>Options: 0 "Internal Res" 1 "External Res" 2 "None"</p>	161 162
		<div style="border: 1px solid black; padding: 5px;">  <p>ATTENTION: The drive does not offer protection for externally mounted brake resistors. A risk of fire exists if external braking resistors are not protected. External resistor packages must be self-protected from over temperature or the protective circuit shown in Appendix C of the User Manual, or equivalent, must be supplied.</p> <p>ATTENTION: Equipment damage may result if a drive mounted (internal) resistor is installed and this parameter is set to "External Res." Thermal protection for the internal resistor will be disabled, resulting in possible device damage.</p> </div>			
UTILITY (File E)	Drive Memory	169	<p>[Flying Start En]</p> <p>Enables/disables the function which reconnects to a spinning motor at actual RPM when a start command is issued.</p>	<p>Default: 0 "Disabled"</p> <p>Options: 0 "Disabled" 1 "Enabled"</p>	170
		201	<p>[Language]</p> <p>Selects the display language when using an LCD HIM. This parameter is not functional with an LED HIM.</p>	<p>Default: 0 "Not Selected"</p> <p>Options: 0 "Not Selected" 1 "English" 2 "Français" 3 "Español" 4 "Italiano" 5 "Deutsch" 6 "Reserved" 7 "Português" 8-9 "Reserved" 10 "Nederlands"</p>	
INPUTS & OUTPUTS (File J)	Analog Inputs	322 325	<p>[Analog In 1 Hi] [Analog In 2 Hi]</p> <p>Sets the highest input value to the analog input x scaling block.</p>	<p>Default: 10.000 Volt 10.000 Volt</p> <p>Min/Max: 4.000/20.000 mA <small>Standard</small>, 0.000/20.000 mA E C, -/+10.000V, 0.000/10.000V</p> <p>Units: 0.001 mA, 0.001 Volt</p>	091 092
		323 326	<p>[Analog In 1 Lo] [Analog In 2 Lo]</p> <p>Sets the lowest input value to the analog input x scaling block.</p>	<p>Default: 0.000 Volt 0.000 Volt</p> <p>Min/Max: 4.000/20.000 mA, 0.000/10.000V (No. 323), -/+10.000V (No. 326) 0.000/10.000V, 0.001 mA, 0.001 Volt</p>	091 092

361	[Digital In1 Sel]	Default: 4	"Stop – CF" ⁽¹⁾																																																																									
	[Digital In2 Sel]	Default: 5	"Start"																																																																									
362	[Digital In3 Sel]	Default: 18	"Auto/ Manual"																																																																									
363	[Digital In4 Sel]	Default: 15	"Speed Sel 1"																																																																									
364	[Digital In5 Sel]	Default: 16	"Speed Sel 2"																																																																									
365	[Digital In6 Sel]	Default: 17	"Speed Sel 3"																																																																									
366	<p>Selects the function for the digital inputs.</p> <p> (1) When [Digital Inx Sel] is set to option 2 "Clear Faults" the Stop button cannot be used to clear a fault condition.</p> <p>(2)</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>3</th> <th>2</th> <th>1</th> <th>"Speed Sel 1-3"</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>0</td><td>Reference A</td></tr> <tr><td>0</td><td>0</td><td>1</td><td>Reference B</td></tr> <tr><td>0</td><td>1</td><td>0</td><td>Preset Speed 2</td></tr> <tr><td>0</td><td>1</td><td>1</td><td>Preset Speed 3</td></tr> <tr><td>1</td><td>0</td><td>0</td><td>Preset Speed 4</td></tr> <tr><td>1</td><td>0</td><td>1</td><td>Preset Speed 5</td></tr> <tr><td>1</td><td>1</td><td>0</td><td>Preset Speed 6</td></tr> <tr><td>1</td><td>1</td><td>1</td><td>Preset Speed 7</td></tr> </tbody> </table> <p>To access Preset Speed 1, set [Speed Ref A Sel] or [Speed Ref B Sel] to "Preset Speed 1".</p> <p>(3)</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>3</th> <th>2</th> <th>1</th> <th>"Spd/Trq Sel1-3"</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>0</td><td>Zero Torque</td></tr> <tr><td>0</td><td>0</td><td>1</td><td>Spd Reg</td></tr> <tr><td>0</td><td>1</td><td>0</td><td>Torque Reg</td></tr> <tr><td>0</td><td>1</td><td>1</td><td>Min Spd/Trq</td></tr> <tr><td>1</td><td>0</td><td>0</td><td>Max Spd/Trq</td></tr> <tr><td>1</td><td>0</td><td>1</td><td>Sum Spd/Trq</td></tr> <tr><td>1</td><td>1</td><td>0</td><td>Absolute</td></tr> <tr><td>1</td><td>1</td><td>1</td><td>Zero Trq</td></tr> </tbody> </table> <p>(4) Enhanced Control Drives Only.</p> <p>(5) Enhanced Firmware V2.001 and later.</p> <p>(6) Opening an "Enable" input will cause the motor to coast-to-stop, ignoring any programmed Stop modes.</p> <p>(7) A dedicated hardware enable input is available via a jumper selection. Refer to the User Manual for further information.</p> <p>(8) Auto/Manual - Refer to the User Manual for details.</p> <p>(9) Typical 3-Wire Inputs - Requires that only 3-wire functions are chosen. Including 2-wire selections will cause a type 2 alarm.</p> <p>(10) Typical 2-Wire Inputs - Requires that only 2-wire functions are chosen. Including 3-wire selections will cause a type 2 alarm.</p> <p>(11) A "Dig In ConflictB" alarm will occur if a "Start" input is programmed without a "Stop" input.</p> <p>Type 2 Alarms - Some digital input programming may cause conflicts that will result in a Type 2 alarm. Example: [Digital In1 Sel] set to 5 "Start" in 3-wire control and [Digital In2 Sel] set to 7 "Run" in 2-wire.</p> <p>Refer to the User Manual for information on resolving this type of conflict.</p> <p>(12) Refer to Option Definitions in the User Manual.</p>	3	2	1	"Speed Sel 1-3"	0	0	0	Reference A	0	0	1	Reference B	0	1	0	Preset Speed 2	0	1	1	Preset Speed 3	1	0	0	Preset Speed 4	1	0	1	Preset Speed 5	1	1	0	Preset Speed 6	1	1	1	Preset Speed 7	3	2	1	"Spd/Trq Sel1-3"	0	0	0	Zero Torque	0	0	1	Spd Reg	0	1	0	Torque Reg	0	1	1	Min Spd/Trq	1	0	0	Max Spd/Trq	1	0	1	Sum Spd/Trq	1	1	0	Absolute	1	1	1	Zero Trq	Options: 0	"Not Used"	
3	2	1	"Speed Sel 1-3"																																																																									
0	0	0	Reference A																																																																									
0	0	1	Reference B																																																																									
0	1	0	Preset Speed 2																																																																									
0	1	1	Preset Speed 3																																																																									
1	0	0	Preset Speed 4																																																																									
1	0	1	Preset Speed 5																																																																									
1	1	0	Preset Speed 6																																																																									
1	1	1	Preset Speed 7																																																																									
3	2	1	"Spd/Trq Sel1-3"																																																																									
0	0	0	Zero Torque																																																																									
0	0	1	Spd Reg																																																																									
0	1	0	Torque Reg																																																																									
0	1	1	Min Spd/Trq																																																																									
1	0	0	Max Spd/Trq																																																																									
1	0	1	Sum Spd/Trq																																																																									
1	1	0	Absolute																																																																									
1	1	1	Zero Trq																																																																									
		1	"Enable" ⁽⁶⁾																																																																									
		2	"Clear Faults" ⁽¹⁾																																																																									
		3	"Aux Fault"																																																																									
		4	"Stop – CF" ⁽¹⁾																																																																									
		5	"Start" ⁽⁹⁾⁽¹¹⁾																																																																									
		6	"Fwd/ Reverse" ⁽⁹⁾																																																																									
		7	"Run" ⁽¹⁰⁾																																																																									
		8	"Run Forward" ⁽³⁾																																																																									
		9	"Run Reverse" ⁽³⁾																																																																									
		10	"Jog" ⁽⁹⁾ "Jog1" ⁽⁴⁾																																																																									
		11	"Jog Forward"	100																																																																								
		12	"Jog Reverse"																																																																									
		13	"Stop Mode B"																																																																									
		14	"Bus Reg Md B"	156																																																																								
		15-17	"Speed Sel 1-3" ⁽²⁾	162																																																																								
		18	"Auto/ Manual" ⁽⁸⁾																																																																									
		19	"Local"																																																																									
		20	"Acc2 & Dec2"																																																																									
		21	"Accel 2"	096																																																																								
		22	"Decel 2"																																																																									
		23	"MOP Inc" ⁽¹²⁾	140																																																																								
		24	"MOP Dec" ⁽¹²⁾																																																																									
		25	"Excl Link" ⁽¹²⁾																																																																									
		26	"PI Enable"	194																																																																								
		27	"PI Hold"																																																																									
		28	"PI Reset"	380																																																																								
		29	"Reserved"	124																																																																								
		30	"Precharge En" ⁽⁴⁾⁽¹²⁾																																																																									
		31-33	"Spd/Trq Sel1-3" ⁽⁵⁾																																																																									
		34	"Jog 2" ⁽⁴⁾																																																																									
		35	"PI Invert" ⁽⁴⁾																																																																									
		36-40	"Reserved"																																																																									
		41-42	"UserSet Sel1-2" ⁽⁵⁾																																																																									
		43	"Run Level" ⁽⁵⁾⁽¹²⁾																																																																									
		44	"RunFwd Level" ⁽⁵⁾⁽¹²⁾																																																																									
		45	"RunRev Level" ⁽⁵⁾⁽¹²⁾																																																																									
		46	"Run w/Comm" ⁽⁵⁾⁽¹²⁾																																																																									

Troubleshooting – Abbreviated Fault & Alarm Listing

For a complete listing of Faults and Alarms, refer to the PowerFlex 70 User Manual.

Fault	No.	Type ⁽¹⁾	Description	Action
Auxiliary Input	2	①	Auxiliary input interlock is open.	Check remote wiring.
Motor Overload	7	① ③	Internal electronic overload trip. Enable/Disable with [Fault Config 1].	An excessive motor load exists. Reduce load so drive output current does not exceed the current set by [Motor NP FLA].
OverSpeed Limit	25	①	Functions such as Slip Compensation or Bus Regulation have attempted to add an output frequency adjustment greater than that programmed in [Overspeed Limit].	Remove excessive load or overhauling conditions or increase [Overspeed Limit].
SW OverCurrent	36	①	Drive output current has exceeded the 1ms current rating. This rating is greater than the 3 second current rating and less than the hardware overcurrent fault level. It is typically 200-250% of the drive continuous rating.	Check for excess load, improper DC boost setting, DC brake volts set too high.
IR Volts Range	77		“Calculate” is the autotune default and the value determined by the autotune procedure for IR Drop Volts is not in the range of acceptable values.	Re-enter motor nameplate data.
FluxAmpsRef Rang	78		The value for flux amps determined by the Autotune procedure exceeds the programmed [Motor NP FLA].	1. Reprogram [Motor NP FLA] with the correct motor nameplate value. 2. Repeat Autotune.

⁽¹⁾ See the User Manual for a description of fault types.

Alarm	No.	Type ⁽¹⁾	Description							
Dig In ConflictA	17	②	Digital input functions are in conflict. Combinations marked with a “” will cause an alarm.							
			Acc2 / Dec2	Accel 2	Decel 2	Jog	Jog Fwd	Jog Rev	Fwd/Rev	
			Acc2 / Dec2							
			Accel 2							
			Decel 2							
			Jog							
			Jog Fwd							
			Jog Rev							
			Fwd / Rev							

www.rockwellautomation.com

Corporate Headquarters

Rockwell Automation, 777 East Wisconsin Avenue, Suite 1400, Milwaukee, WI, 53202-5302 USA, Tel: (1) 414.212.5200, Fax: (1) 414.212.5201

Headquarters for Allen-Bradley Products, Rockwell Software Products and Global Manufacturing Solutions

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation SA/NV, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Headquarters for Dodge and Reliance Electric Products

Americas: Rockwell Automation, 6040 Ponders Court, Greenville, SC 29615-4617 USA, Tel: (1) 864.297.4800, Fax: (1) 864.281.2433
Europe/Middle East/Africa: Rockwell Automation, Brühlstraße 22, D-74834 Eitztal-Dallau, Germany, Tel: (49) 6261 9410, Fax: (49) 6261 17741
Asia Pacific: Rockwell Automation, 55 Newton Road, #11-01/02 Revenue House, Singapore 307987, Tel: (65) 6356-9077, Fax: (65) 6356-9011

U.S. Allen-Bradley Drives Technical Support

Tel: (1) 262.512.8176, Fax: (1) 262.512.2222, Email: support@drives.ra.rockwell.com, Online: www.ab.com/support/abdrives