

Procedure to prepare ePro to comm. as backup to equipment

1. Connect all cables & Power up the ePro.
2. On ePro, exit existing application and get back to the windows screen.
3. Plug in the memory stick where files located at.
4. Open explore & Delete all files located in the **D:\ drive**
5. Select & Copy all the Files (for the equipment to be used as backup) from the memory stick to the **D:\ drive**
6. Configure the ePro TCP/IP to the correct IP address (under Network Connection)
 - a. CPM 192.168.100.112
 - b. MBS 192.168.100.113
 - c. Curing 192.168.100.114
 - d. Pallet Handling 192.168.100.115
 - e. QBR 192.168.100.117
7. Open KepServer (Start → All programs → Canvas Software → KepServer_ePro → KepServer_ePro)
8. Select & open the *.opf file located in the **D:\ drive**
9. Test connection (Select Tools → OPC Quick Client)
10. Click on multiple folders and verify quality “Good”). If quality indicated “Bad” then check cable, connection, or IP address)
11. Close all without Save
12. Performed “Protected Mode Save” on the ePro.
13. Run application if not start Automatically after reboot (Start → All programs → Canvas Start
14. Verify the running application ----- **DONE**